

WF-Series provides the modularized standard fixtures to mount all models of Wonpro receptacles, switches, bell push button, TV cable and telephone wire connectors.

WF SERIES



WF-S1L

Switch set, one large gang, 3 way
2 use, 15A 250V AC (with indicator)



WF-1.S1

Switch set, 1 gang, 3 way
2 use, 15A 250V AC (with indicator)



WF-2.S2

Switch set, 2 gang, 3 way
2 use, 15A 250V AC (with indicator)




WF-3.S3

Switch set, 3 gang 3 way
2 use, 15A 250V AC (with indicator)



WF-3.S4

Switch set, 4 gang, 4 way
2 use, 15A 250V AC (with indicator)



WF-1.R6A

Receptacle set



WF-2.R6A

Receptacle set



WF-2.S1.R6A

1 switch & receptacle set




WF-1.R5A

Receptacle set (earth type)




WF-2.R5A

Receptacle set (earth type)




WF-1.B1

Electric bell press set




WF-1.TV1

TV. antenna receptacle set



WF-1.TE1

Telephone switch set
(2 wires)




WF-1.R4

Universal receptacle set




WF-1.RU4T

Universal receptacle set
250V (for air-conditioner use)
(screw type terminals)




WF-3.S5

Switch set, 5 gang, 3 way
2 use, 15A 250V AC (with indicator)




WF-3.S6

Switch set, 6 gang, 3 way
2 use, 15A 250V AC (with indicator)




WF-3.S3.R6A2

3 gang switch & 2 receptacle set




WF-3.S3.R5A2

3 gang switch & 2 receptacle set




WF-2.R5A.RU4

Universal receptacle set
110V/220V




WFN-o

Blind panel




WFN-2.NTE1

2 telephone receptacle set (2 wires)




WFN-1.NTV1

TV receptacle set (terminal type)




WF-2.O.R4

Universal & circuit breaker
receptacle set




WFN-1

1 universal panel



WFN-2

2 universal panel



WFN-3

3 universal panel

PARTS

Common panels & frames
by interchangeable receptacles or switches


EXCEL SYSTEM

WF SERIES

Model No.


Remarks

WF-1




Panel & frame (For one unit use)
1 socket or 1 gang switch use

WF-2



Panel & frame (For two or three units use)
2 sockets use, 2 gang or 3 gang switches use.


WF-3




Panel & frame (For four-five-six units use) 4 sockets use,
4 gang, 5 gang or 6 gang switches use.

FITTING

THE NAKED BRASS
CONDUCTOR MUST BE 13MM.




TO INSTALL, INSERT THE
CONDUCTING WIRE
DIRECTLY. TO TAKE OUT,
PRESS DOWN THE WHITE
BUTTON.




TO TAKE
DOWN THE
RECEPTACLE
OR THE SWITCH,
INSERT THE
SCREW DRIVER
INTO THE
INDICATED NOTCH &
AT THE SAME TIME,
MOVE THE SCREW
DRIVER IN THE
DIRECTION OF THE
ARROW AS SHOWN.

WF-2



WF-3



Dimension: mm

KITS

Special use receptacle set

EXCEL SYSTEM


WF SERIES

Model No.

Suitable for factory testing use or install on the electronic instrument/equipment.


WF-8.R4.R5A (convex type)

Pallet receptacle set




WF-9.R4 (buried type)


Pallet receptacle set



WF-8



WF-9




WF-8.R4



WF-8.R320.R4



WF-8.R320.R5A



WF-9.R4.R5A



WF-9.R320.R4



WF-9.R320.R5A




Exclude
circuit breaker
and
indicator


Dimension: mm

WF SERIES


WF-6C Panel



WF-6C Fixing Frame



WF-6 Simple Panel



The fitting & function of various component parts under this series, please see page 4 to 7.

S=Switch

R=Receptacle

R320=Computer receptacle

B=Electric bell


TV=TV receptacle

TE=Phone receptacle


O=Overload no fuse

circuit breaker

F=Panel




WF-6C.S1




WF-6C.R2




WF-6C.B1



WF-6C.TV1




WF-6C.TE1




WF-6C.R5A




WF-6C.R13A




WF-6C.O



WF-6C.R320




WF-6C.R4




WF-6C.C1

WF-6C2 Panel




WF-6C2 Fixing Frame


In order to mate the requirement of this series, please bury the fixed holes to the wall as the arrow shown.




L x W x H
72x72x37




WF-6C2.S1L




WF-6C2.S2




WF-6C2.S3




WF-6C2.R5A




WF-6C2.O.R5A




WF-6C2.R320.R5A




WF-6C2.R2




WF-6C2.R13A




WF-6C2.O.R13A




WF-6C2.R320.R13A




WF-6C2.TE1




WF-6C2.R4



WF-6C2.O.R4



WF-6C2.R320.R4



WF-6C2.S1.R4